

# **GV-LPR CAM V1.6**Installation Guide

Before attempting to connect or operate this product, please read these instructions carefully and save this manual for future use.

© 2010 April GeoVision Inc. All rights reserved.

LPRCAMV16-A

### Models

GV-LPR CAM offers a selection of models that support different video formats to meet various needs. This installation guide will take you through the functionality and use of GV-LPR CAM.

#### List of Models

Model	IR Optimal Distance	Video Format	
GV-LPR CAM 10M EIA DC12V	10 m / 32.80 ft	NTSC	
GV-LPR CAM 10M CCIR DC12V	10 m / 32.80 ft	PAL	

## **Packing List**


- AC Power Cable (110-125V, 10A) x 1
- Power Adapter (100-240V, 12V/3A) x 1
- Outdoor Mounting Bracket x 1

## **Specifications**

Model	GV-LPR CAM 10M EIA DC 12V	GV-LPR CAM 10M CCIR DC 12V	
Sensor	1/3" B/W EXview CCD		
Resolution	570 TVL		
Lens Focal Length	5 ~ 50 mm, 10X		
Construction	Robust aluminum with weatherproof sun-shield		
Protection classification	IP 66		
Temperature	Operation: -20°C ~ 50°C / -4°F ~ 122°F	Storage: -20°C ~ 70°C / -4°F ~ 158°F	
Power Supply	DC 12V		
Power Consumption	15W		
LED Quantity	7 high-efficient LEDs		
IR Distance	12 m / 39.37 ft		
	7 ~ 12 m / 22.96 ~	39.37 ft (optimal)	
Illumination View Angle	30	)°	
Illuminator Life	25,000 hrs		

## Installing Camera Module

1. Push the sun shield forward to align with the back of camera enclosure.



Camera Enclosure Back

Loosen the set screws on the back of the camera enclosure.





3. Pull out the camera module.



Camera Module


 Slightly lift the camera module and slide it out completely.





Completely slide the camera module out


5. Remove the foam.



6. Loosen the screw cap on the right.



7. Insert the video cable through the screw cap and the inside rubber of the cap.



 Attach the video cable to the BNC connector and plug it into the "VIDEO OUT" jack.



Adjust the length of the video cable and seal it with the waterproof tape.




10. Tightly screw the cap.



 Loosen the screw cap on the left, insert the power cable through the screw cap and the inside rubber.



12. Remove the terminal block. Plug black and white wires of the power cable to the terminal block. Reinsert the terminal block onto the camera. The white wire is required to connect to the positive pin (+) on the camera and the black wire to the negative pin (-).



 Adjust the length of the cable, seal it with the waterproof tape, and then tightly screw the cap (see Steps 9 and 10 for the pictures).

## Adjusting Camera Settings

#### Overview



No	Function
1	Auto Iris lens connector
2	Video out
3	Power Terminal (It is already connected. Follow Steps 11 to 12 in Installing Camera
	Module to insert the Power Cable.)
4	Moves down the OSD menu.
5	Moves the focus rightward to select menu options.
6	Power LED
7	Moves up the OSD menu.
8	Enters the OSD menu option and confirms the selection
9	Moves the focus leftward to select menu options.

#### Shutter Speed

See the lists below for shutter speed settings.

Distance between the object and the camera is 550 cm (18.04 ft).		
165 SEC		
182 SEC		
183 (*) SEC		
184 SEC		
185 SEC		
225 SEC		

Distance between the object and the camera is 1100 cm (36.08 ft).
145 SEC
150 SEC
155 SEC
170 SEC
180 SEC
200 SEC


#### Notes:

- 1. The default settings are marked with (\*).
- 2. The gray areas in the charts are not recommended for use.

#### **LED Brightness Settings**

The GV-LPR CAM models come with 7 LEDs which you can adjust the brightness. You can push up (ON) and down (OFF) the switches for LED brightness settings. See the table below for 4 setting values.

SW (1)	SW (2)	LED Brightness (mA)	
ON	ON	470 (Default Setting)	
ON	OFF	300	
OFF	ON	200	
OFF	OFF	100	



#### **OSD Menu Options and Functions**

Main Menu	Sub	Menu	Function	Default Setting
LENS	MANUAL		Manually adjust the camera lens.	✓
	DC		Press <b>SET</b> to adjust the lens brightness.	-
SHUTTER	FIXE	D	Includes these options: 1/60, 1/100, 1/250,	1/500
			1/500, 1/2000, 1/5000, 1/10000, 1/100000.	
	MANUAL		Press SET to manually adjust the shutter	-
			speed.	
	AUTO		Not available when the LENS is set at DC.	Brightness: 70
BLC	OFF		Turn off BLC function.	✓
(Backlight	ON BLC AREA		Press <b>SET</b> to configure the areas.	-
Compensation)		BLC RATIO	Press <b>SET</b> to adjust the sensitivity values.	-
AGC (Automatic	OFF		Turn off AGC function.	✓
Gain Control)	ON		Press <b>SET</b> to adjust the AGC ratio values.	-
WHITE BAL.	ATW		Auto Tracking White Balance	✓
(White Balance)	AWB		Automatic White Balance	-
	FIXED		Press <b>SET</b> to select the mode from 1 to 4.	-
	MANUAL		Press SET to adjust Red and Blue gain.	-
ADJUST	CONTRAST		Adjust the Contrast from values 0 to 255.	87
	SHARPNESS		Adjust the Sharpness from values 0 to 255.	10
	CB_GAIN		Adjust CB_GAIN from values 0 to 255.	176
	CR_GAIN		Adjust CR_GAIN from values 0 to 255.	176
FUNCTION	CMAERA ID		Press <b>SET</b> to name the camera.	OFF
	MIRROR		Select <b>ON</b> to reverse the image.	OFF
	MOTION		Select ON and press SET to configure	OFF
			MOTION areas.	
	PRIV	/ACY	Select ON and press SET to configure	OFF
			PRIVACY areas.	
	GAN	IMA	Adjust the gamma values to control brightness.	1
			Higher gamma value shows darker images.	
	LANGUAGE		Press SET to change the language setting of	English
			OSD menu options.	
RESET	-		Press <b>SET</b> to restore to the factory defaults.	-
EXIT	EXIT -		Close the OSD menu.	-

Note: The factory default GAMMA value is set to be 1. It will be adjusted to 0.45 every time when you select RESET. For optimal image performance, it is recommended to adjust the GAMMA value to 1.

## Installing Camera Enclosure

After the installation of camera module and settings adjustment, you are now ready to install the camera enclosure back.

1. Adjust the lens focus.



2. Lift the camera module.



3. Align the camera module to the camera 4. enclosure and slide it back.



Secure the camera enclosure with the screws on both sides.



5. Push the sun shield back.





9F, No. 246, Sec. 1, Neihu Rd., Neihu District, Taipei, Taiwan Tel: +886-2-8797-8377 Fax: +886-2-8797-8335 sales@geovision.com.tw http://www.geovision.com.tw