

Table Of Contents

Chapter 1	Installing Hardware and Software	
	Hardware Installation	1
	Installing Video Capture Card (GV Card) to PC	1
	Connecting the BNC Extension Card	3
	Connecting the D-Type Video Extension Cable	4
	Connecting Watchdog	4
	Connecting Real-Time Display Card	5
	Connecting Audio Extension Card	6
	Connecting 16-Channel Audio Recording Card (GV-A16)	6
	Connecting GV-NET Card and GV-NET/IO Card	7
	Connecting GV-NET, GV-IO, and GV-RELAY Modules	9
	Connecting GV-Data Capture Box	10
	Connecting IR Remote Control	11
	Software Installation	12
Chapter 2	Configuring Main System	
	System Configuration	13
	Configuring Global Recording Parameters	16
	Adjusting Individual Camera	22
	Setting Up Day-Night Recording Mode	25
	Setting Up I/O Devices	25
	Configuring Hotline/Network Notification	28
	Selecting Screen Layout	30
	Launching GV-System from System Tray	31
	Camera / Audio Install	32
	Setting Up Auto Reboot	32
	Logging System Activities into System Log	33
	Moving PTZ Camera to a Preset Location Upon Alarm Event	35
	Deactivating Alarm and Alert Settings	36
	Popping Up a Camera Window on Motion Detection	36
	Configuring Object Counting	37
	Mapping PTZ Cameras	39
	Setting Up Password	40
	Sending Alerts thru E-mail Accounts	41
	Choosing Video Source	43
	Optimizing System Performance	43

Adjusting Video Attributes	44
Switching to Full-Screen View	45
Listening to Live Audio	45
Deactivating Video Lost Beep	46
Start/Stop Monitoring	46
Playing Back Video Files	46
System Log	47
Running the System at a Schedule Time	50
Configuring I/O Schedule	52
PTZ Control Panel	52
Auto Switching PTZ Control Panels	53
I/O Control Panel	54
I/O Input Control Panel	54
I/O Output Control Panel	54
Touch Screen Support	55
PTZ and I/O Control Panel	55
Touch Screen Panel	55
Retrieving Images Using Object Index	56
Object Index Setup	56
Live Object Index	57
Object Index Search	58
Detecting Unattended and Missing Objects	60
Detecting Unattended Objects	60
Detecting Missing Objects	62
Object Tracking and Zooming	63
Object Tracking	63
Starting Object Tracking	67
Zooming in Objects	67
Object Zooming	69
Starting Object Zooming	70
Displaying the Fast Key Window	71
Fast Key Reference	72

Chapter 3

Point-Of-Sale (POS) Application

POS System Connection	73
Setting a POS System	74
Superimposing POS Data onto Camera Screen	76
POS Field Filter	77

	Abnormal Transaction Alerts	79
Chapter 4	Playing Back Video Files	
	Playing Back on ViewLog	81
	Playback Screen Layout	84
	Searching a Video Event	85
	Playback Control Buttons	86
	Adjusting Video Characteristics	86
	Exporting Video to Play Back at Third Party Viewers	86
	Object Search	87
	Searching and Playing back Motion, Alarm, and POS Event	89
	Advanced Setup	91
	Recycling Option for Video Files	93
	Unmarking All Never-Recycling Flags	93
	Reserving Never-Recycling Flags	94
	Playing Back across Local Area Network	94
	Displaying the Fast Key Window	96
	Fast Key Reference	96
	Playing Back over Internet	97
	Working with Remote Playback Server at the Server PC	97
	Working with Remote Playback Client at the Client PC	99
Chapter 5	Backing Up Video Files	
	Backup Audio/Video Files with Backup System	105
	Backup Audio/Video Files with ViewLog	108
	Quick Backup	108
	Backup Log	109
	Backing Up at the Client PC	109
	Deleting Audio/Video Files	110
	Repairing the Damaged File Paths	111
Chapter 6	Viewing Live Video Using WebCam	
	Configuring the WebCam Server	113
	IP White List Setup	115
	Video Setup	116
	Bandwidth Setup	116
	Connecting Audio Devices	117
	Audio Setup	117

FTP Server Setup	118
Starting WebCam at the Client PC	118
Single View MPEG4 Encoder Viewer	121
Administrating Host Server	122
Taking a Snapshot from a Live Video	122
Pop-up Setup	123
Saving Files to Play Back at Third-Party Viewers	123
PTZ Control	124
Output Control	124
Two Way Audio	125
Data Rate Configuration	125
Multi View MPEG4 Encoder Viewer	126
Working with the Host Server Window	127
Saving Files to Play Back at Third-Party Viewers	128
Taking a Snapshot from a Live Video	128
PTZ Control	128
Output Control	129
Channel Status Information	129
Camera Polling Function	129
Two Way Audio	130
Multi View Configuration	130
Creating a Quick Connection to a Host Server	130
Creating a Multiple Host	131
Camera Status	133
Host Information	133
JPEG Image Viewer	134
Remote Playback on WebCam	135
Searching and Playing Back Recorded Files	136
Advanced Search	136
Remote Control Using Remote Desktop	139
Remote Viewing with PDA	140
Remote Viewing with I-Mode	142

Chapter 7

E-Map Application	
The E-Map Editor Window	145
Creating an E-Map File	147
Creating an E-Map File for a Remote Host	147
Starting E-Map	148

	Setting the Pop-up Map Function	149
	Starting E-Map from a Remote Site	150
	The Remote E-Map Window	150
	Logging in Different Hosts	152
	Configuring the Remote E-Map Window	152
Chapter 8	Live Viewing Using Remote Applications	
	Remote View	153
	Setting Up Remote View	153
	Working With My Favorite	155
	Camera Zoom Function	156
	Playing Back Video Files In Q-View	157
	Preference Settings	158
	Remote PTZ and I/O function	159
	Full Screen View	160
	IP Multicast	161
	Setting Up IP Multicast	161
	Starting IP Multicast	161
Chapter 9	Central Monitoring by Center V2	
	Installing Center V2	163
	The Center V2 Window	164
	Creating a Subscriber Account	167
	Configuring Center V2	170
	General Settings	171
	Network Settings	172
	Record Settings	172
	Dispatch Server Settings	173
	Subscribing to Center V2	173
	Normal Mode Setup	174
	Panic Button Setup	177
	Incoming Events to Center V2	178
	Opening the Event Log	178
	Filtering the Event Log	179
	Applying Multiple Filters	179
	Removing Filters	180
	Event Log Settings	180
	Monitoring and Managing Subscribers	180

	I/O Control	180
	Two-Way Audio Control	181
	PTZ Control	182
	Viewing Subscriber Information	182
	Controls in the Subscriber Status	182
	Output Alerts	183
	Setting Output Devices	183
	Forcing Output Devices	183
	Notification Settings	183
	SMS Alerts	184
	Connecting to the SMS Server	184
	Sending SMS	184
Chapter 10	Distributed Monitoring Requests thru Dispatch Server	
	Installing Dispatch Server	185
	The Dispatch Server Window	186
	Creating a Subscriber Account	187
	Advanced Settings	188
	Starting Dispatch Server	190
	Connecting Center V2 to Dispatch Server	190
	Connecting GV System to Dispatch Server	191
	Querying an Event on Center V2	191
	Displaying Real-Time Events of Center V2	192
	Launching the Log Browser	193
	Dispatch Log Browser	193
	Event Log Browser	194
Chapter 11	Central Monitoring by Vital Sign Monitor	
	Installing VSM	195
	The VSM Window	196
	Creating a Subscriber Account	198
	Configuring VSM	199
	System Configuration	199
	Password Settings	200
	Event Log Settings	200
	Notification Settings	200
	Output Settings	201
	Starting VSM	201

	Subscribing to VSM	201
	Advanced Settings for Subscription	202
	General Settings	202
	Monitor Control Settings	203
	Activating Output Devices	204
	Forcing Outputs of VSM	204
	Forcing Outputs of Subscribers	204
	SMS Alerts	205
	Connecting to the SMS server	205
	Sending SMS	205
Chapter 12	Short Message Service	
	SMS Server Setup	207
	Starting SMS Server	207
	Password Security	208
	Creating a Client Account	209
	Configuring Event Log	209
	Connecting GV-system to SMS Server	210
	Setting Mobile Phone Numbers	211
Chapter 13	Useful Utilities	
	Using Dynamic DNS	213
	Installing Dynamic DNS	213
	Registering Domain Name with DDNS	214
	Twin DVR System	216
	Twin Server Setup	217
	Multicast Settings	218
	Twin DVR Installation and Setup	218
	Installing Twin DVR	218
	Running Twin DVR	219
	Watermark Viewer	222
	Using GV-System in Twin View Display	224
	Windows Lockup	226
	The GV-desktop Screen	226
	GV-desktop Features	227
Troubleshooting		231