

Table Of Contents

Chapter 1	Installing Hardware and Software	
	Hardware Installation	1
	Installing Video Capture Card (GV Card) to PC	1
	Connecting the BNC Extension Card	3
	Connecting the D-Type Video Extension Cable	4
	Connecting Watchdog	4
	Connecting Real-Time Display Card	5
	Connecting Audio Extension Card	6
	Connecting 16-Channel Audio Recording Card (GV-A16)	6
	Connecting GV-NET Card and GV-NET/IO Card	7
	Connecting Hybrid DVR Card	8
	Connecting GV-NET, GV-IO, and GV-RELAY Modules	11
	Connecting GV-Hub	12
	Connecting GV-Data Capture Box	13
	Connecting IR Remote Control	14
	Connecting GV-Keyboard	14
	Software Installation	15
	USB Dongle Driver for V7.0 Upgrade	16
Chapter 2	Configuring Main System	
	System Configuration	19
	Configuring Global Recording Parameters	20
	Adjusting Individual Camera	26
	Setting Up Day-Night Recording Mode	29
	Setting Up I/O Devices	29
	Configuring Hotline/Network Notification	32
	Selecting Screen Layout	34
	Launching GV-System from System Tray	35
	Camera / Audio Install	36
	Setting Up Auto Reboot	36
	Logging System Activities into System Log	37
	Moving PTZ Camera to a Preset Location Upon Alarm Event	39
	Deactivating Alarm and Alert Settings	40
	Popping Up a Camera Window on Motion Detection	40
	Configuring Object Counting	41
	Mapping PTZ Cameras	43

Setting Up Password	44
Sending Alerts thru E-mail Accounts	45
Choosing Video Source	47
Optimizing System Performance	48
Adjusting Video Attributes	44
Switching to Full-Screen View	49
Listening to Live Audio	49
Deactivating Video Lost Beep	50
Start/Stop Monitoring	50
Playing Back Video Files	50
System Log	51
Recording Schedule	54
PTZ Control Panel	57
Auto Switching PTZ Control Panels	57
I/O Control Panel	58
I/O Input Control Panel	58
I/O Output Control Panel	59
Touch Screen Support	59
PTZ and I/O Control Panel	59
Touch Screen Panel	59
Retrieving Images Using Object Index	60
Object Index Setup	60
Live Object Index	62
Object Index Search	63
Detecting Unattended and Missing Objects	64
Detecting Unattended Objects	64
Detecting Missing Objects	66
Object Tracking and Zooming	67
Object Tracking	68
Starting Object Tracking	72
Zooming in Objects	72
Object Zooming	73
Starting Object Zooming	74
Configuring Hybrid Cameras	75
Fast Key Reference	76

Chapter 3	Point-Of-Sale (POS) Application	
	POS System Connection	79
	Setting a POS System	81
	Superimposing POS Data onto Camera Screen	82
	POS Field Filter	84
	Abnormal Transaction Alerts	85
	Codepage Mapping	86
	Searching POS Data	87
 Chapter 4	 Playing Back Video Files	
	Playing Back on ViewLog	89
	Playback Screen Layout	92
	Playback Control Buttons	93
	A to B Playback Mode	93
	Searching a Video Event	94
	Exporting Video	95
	Object Search	97
	Searching and Playing back Motion, Alarm, and POS Event	99
	Advanced Setup	101
	Recycling Option for Video Files	103
	Unmarking All Never-Recycling Flags	104
	Reserving Never-Recycling Flags	104
	Fast Key Reference	105
	Playing Back across Local Area Network (LAN)	106
	Playing Back over Internet	108
	Working with Remote Playback Server at the Server PC	108
	Working with Remote Playback Client at the Client PC	110
 Chapter 5	 Backing Up Video Files	
	Backup Audio/Video Files with Backup System	117
	Backup Audio/Video Files with ViewLog	120
	Quick Backup	120
	Advanced Backup	121
	Backing Up at the Client PC	122
	Deleting Audio/Video Files	123
	Repairing the Damaged File Paths	124

Chapter 6	Viewing Live Video Using WebCam	
	Configuring the WebCam Server	125
	General Settings	126
	Server Settings	126
	Video Settings	127
	RPS Settings	128
	Audio Settings	128
	JPG Settings	130
	IP White List Settings	130
	FTP Server Settings	131
	Starting WebCam at the Client PC	132
	Single View MPEG4 Encoder Viewer	134
	Administrating Host Server	135
	Taking a Snapshot from a Live Video	136
	Pop-up Setup	136
	Exporting Video	137
	PTZ Control	137
	Output Control	138
	Two Way Audio	138
	Data Rate Configuration	138
	DirectDraw Setup	139
	Multi View MPEG4 Encoder Viewer	139
	Working with the Host Server Window	141
	Exporting Video	141
	Taking a Snapshot from a Live Video	141
	PTZ Control	142
	Output Control	142
	Channel Status Information	143
	Camera Polling Function	143
	Two Way Audio	144
	Multi View Configuration	144
	Creating a Quick Connection to a Host Server	145
	Creating a Multiple Host	145
	Camera Status	147
	Host Information	148
	JPEG Image Viewer	149
	Remote Playback on WebCam	149
	Searching and Playing Back Recorded Files	150

	Synchronizing Audio with Video Playback	151
	DirectDraw Setup	151
	Searching Object Index	151
	Advanced Search	152
	Remote Control Using Remote Desktop	154
	Remote Viewing with PDA	155
	G-View Installation	155
	Connecting G-View to GV-Server	155
	Viewing GV-Server Information	157
	Remote Viewing with Mobile Phone	157
	I-Mode Phone	158
	Windows Smartphone	159
	Symbian Smartphone	160
	Fast Key Reference	
	The Multi View Window	162
	PTZ Control in Multi View	163
Chapter 7	E-Map Application	
	The E-Map Editor	165
	Creating an E-Map File	167
	Creating an E-Map File for a Remote Host	167
	Starting E-Map	168
	Setting the Pop-up Map Function	170
	Starting E-Map from a Remote Site	170
	The Remote E-Map Window	171
	Logging in Different Hosts	172
	Configuring the Remote E-Map Window	172
	Viewing Host Information	173
Chapter 8	Live Viewing Using Remote Applications	
	Remote View	175
	Setting Up Remote View	175
	Working With My Favorite	177
	Camera Zoom Function	178
	Playing Back Video Files In Q-View	179
	Preference Settings	180
	Remote PTZ and I/O function	181
	Full Screen View	182

	IP Multicast	183
	Setting up IP Multicast	183
	Starting IP Multicast	183
Chapter 9	Central Monitoring by Center V2	
	Installing Center V2	185
	The Center V2 Window	186
	Creating a Subscriber Account	188
	Configuring Center V2	192
	General Settings	192
	Layout Settings	193
	Network Settings	194
	Record Settings	195
	Dispatch Server Settings	195
	Connecting to Center V2	196
	Normal Mode Setup	196
	Panic Button Setup	199
	Incoming Events to Center V2	200
	Opening the Event Log	201
	Filtering the Event Log	201
	Applying Multiple Filters	202
	Removing Filters	202
	Event Log Settings	202
	Monitoring and Managing Subscribers	203
	I/O Control	203
	Two-Way Audio Control	203
	PTZ Control	204
	Camera Monitor	204
	Viewing Subscriber Information	205
	Controls in the Subscriber Status	206
	Output Alerts	206
	Setting Output Devices	206
	Forcing Output Devices	207
	Notification Settings	207
	SMS Alerts	208
	Connecting to the SMS Server	208
	Sending SMS	208

	E-Mail Alerts	209
	Setting Mailbox	209
	Sending E-Mail	210
Chapter 10	Distributed Monitoring Requests thru Dispatch Server	
	Installing Dispatch Server	211
	The Dispatch Server Window	212
	Creating a Subscriber Account	213
	Advanced Settings	214
	Starting Dispatch Server	216
	Connecting Center V2 to Dispatch Server	216
	Connecting GV System to Dispatch Server	217
	Querying an Event on Center V2	217
	Displaying Real-Time Events of Center V2	218
	Launching the Log Browser	219
	Dispatch Log Browser	219
	Event Log Browser	219
Chapter 11	Central Monitoring by Vital Sign Monitor	
	Installing VSM	221
	The VSM Window	222
	Creating a Subscriber Account	224
	Configuring VSM	224
	System Configuration	224
	Password Settings	226
	Event Log Settings	226
	Notification Settings	226
	Output Settings	226
	E-Mail Settings	226
	Starting VSM	227
	Connecting to VSM	227
	Advanced Settings for Subscription	228
	General Settings	228
	Camera & I/O Settings	229
	System Information Settings	230
	Monitoring Subscribers	230
	Viewing Subscriber Status	230
	Viewing Storage Information	232

	Activating Output Devices	232
	Forcing Outputs of VSM	232
	Forcing Outputs of Subscribers	233
	SMS Alerts	233
	Connecting to the SMS server	233
	Sending SMS	234
	E-Mail Alerts	234
Chapter 12	Short Message Service	
	Installing SMS Server	235
	SMS Server Setup	235
	Device Settings	236
	Server Settings	237
	Account Settings	240
	SMS Log	242
	Setting SMS Log	242
	Viewing SMS Log	242
	Password Security	243
	Connecting GV-system to SMS Server	243
	Setting Mobile Phone Numbers	244
Chapter 13	Useful Utilities	
	Dynamic DNS	247
	Installing Dynamic DNS	247
	Registering Domain Name with DDNS	248
	TwinDVR System	250
	Starting TwinServer	251
	Installing TwinDVR	252
	Starting TwinDVR	253
	TwinDVR Settings	255
	Watermark Viewer	256
	Twin View Display	258
	Windows Lockup	260
	The GV-desktop Screen	260
	GV-desktop Features	261
	Authentication Server	265
	Installing the Server	265
	The Server Window	265

Creating a DVR List	266
Editing a User	267
Starting the Server	268
Connecting GV System to the Server	269
Troubleshooting	271