



FAQ Index

Top FAQ from October to April.....	2
DVR / NVR Monitoring Software.....	6
DVR / NVR System	13
DVR Capture Card, Accessories	13
DVR / NVR Playback	16
Remote / Mobile Viewing	17
Retail Solution, POS Integration	21
IP Devices (GV-IP Camera, GV-Video Server, GV-Compact DVR).....	22
IP Camera Only.....	26
CMS	31
Access Control and LPR	33
Digital Signage	37
For All GeoVision Products.....	37



Top FAQ from October to March

Date	Title	Applied to
2014/04/07	Why does an "Entry Point Not Found" message appear in GV-Dispatch Server? NEW! http://pd.geovision.tw/faq/CMS/GV-Dispatch_Server_XP_message_solution.pdf	GV-Dispatch Server V8.5.9 or later
2014/04/07	Why doesn't Live View display when Pelco Spectra IV IP series is connected to GV-System? NEW! http://pd.geovision.tw/faq/MonitoringSW/GV-System_connection_Pelco_Spectra_solution.pdf	GV-System
2014/03/31	Why does the GV-IP Decoder Box / GV-Pad show the "Resolution Error" or "Codec Error" message? NEW! http://pd.geovision.tw/faq/IPCamera/Decoder_box_quad_view_error.pdf	GV-IP Decoder Box / GV-Pad firmware V1.05 or later
2014/03/28	How to solve GV-IP Camera light flicker issue? NEW! http://pd.geovision.tw/faq/IPCamera/GV-IP_Camera_light_flicker_solution.pdf	GV-IP Camera
2014/03/07	How do I connect GV-SD200 with Multi View (DMMultiView)? NEW! http://pd.geovision.tw/faq/Remote_Mobile/Connecting_GV-SD200_with_MultiView.pdf	GV-Multi View
2014/02/10	How do I run Remote ViewLog using a non-administrator account? NEW! http://pd.geovision.tw/faq/Playback/Running_Remote_ViewLog_using_non-admin_account.pdf	Remote ViewLog V8.5.7 or later



2014/02/07	The maximum power consumption of GV-IP Cameras UPDATED! http://pd.geovision.tw/faq/IPCamera/IPCAM_Power_consumption.pdf	GV-IP Camera
2014/02/07	The supported power types for GV-IP Cameras UPDATED! http://pd.geovision.tw/faq/IPDevice/Supported_IPCAM_Power.pdf	GV-IP Camera
2014/02/07	Does GV-POE Switch support SFP+? UPDATED! http://pd.geovision.tw/faq/CaptureCard_Accessory/GV-POE_switch_supports_SFP+.pdf	GV-POE Switch
2014/02/06	LPR images captured from GV-Video Server and GV-Compact DVR appear interlaced NEW! http://pd.geovision.tw/faq/AccessControl/Interlaced_LPR_Image_from_Standalone.pdf	GV-ASManager V4.0 GV-DVR LPR GV-Compact DVR GV-Video Server
2014/01/09	Why does the GV-IP camera's 320 x 240 image not fill up the TV monitoring screen? NEW! http://pd.geovision.tw/faq/IPCamera/IPCam_320x240_image_not_fill_up_TV_screen.pdf	GV-BX, GV-BX-E, GV-VD and GV-FD Series
2014/01/08	Why does the GV-UBL Camera show a white circular image during night surveillance? NEW! http://pd.geovision.tw/faq/IPCamera/UBLCam_show_a_white_circular_image_at_night.pdf	GV-UBL Series



2014/01/03	<p>Why can't I access live view on GV-Mobile Server using Chrome and Firefox? NEW!</p> <p>http://pd.geovision.tw/faq/Remote_Mobile/MobileServer_Chrome_Firefox_Issue.pdf</p>	GV-Mobile Server V1.3 - V1.4.1
2013/12/04	<p>Which GV-IP Cameras support recording of 1920 x 1080 at 25 fps? NEW!</p> <p>http://pd.geovision.tw/faq/IPCamera/IPCam_support_full_HD_recording_25fps.pdf</p>	GV-IP Camera
2013/11/28	<p>How do I delete the connection history of Remote ViewLog? NEW!</p> <p>http://pd.geovision.tw/faq/Remote_Mobile/RemoteViewLog_Delete_History.pdf</p>	Remote ViewLog
2013/11/19	<p>Which brands of wireless access points have been tested for GeoVision wireless cameras? NEW!</p> <p>http://pd.geovision.tw/faq/IPCamera/Tested_Wireless_Access_Point.pdf</p>	GV-BX1200 Series / 1300 Series / 1500 Series / 2400 Series / 3400 Series / 5300 Series, GV-CAW120 / 220, GV-CBW120 / 220, GV-MFD1501 Series / 2401 Series / 3401 Series / 5301 Series
2013/11/13	<p>Which countries' license plates are supported by GeoVision LPR system? NEW!</p> <p>http://pd.geovision.tw/faq/AccessControl/LPR_plates_supported_country.pdf</p>	GV-DVR LPR software, GV-DSP LPR V3 firmware



2013/11/12	How do I change the recording resolution when using GV-SDI-204 Cards? NEW! http://pd.geovision.tw/faq/CaptureCard_Accessory/HD-SDI_resolution.pdf	GV-SDI-204 Video Capture Card
2013/11/12	Is it possible for GV-SDI-204 Cards to support audio? NEW! http://pd.geovision.tw/faq/CaptureCard_Accessory/SDI_Card_Audio.pdf	GV-SDI-204 Video Capture Card
2013/11/01	GV-iView and GV-iView HD for iOS NEW! http://pd.geovision.tw/faq/Remote_Mobile/FAQ_GV-iView_iViewHD_for_iOS.pdf	GV-iView and GV-iView HD
2013/11/01	GV-AView for Android NEW! http://pd.geovision.tw/faq/Remote_Mobile/FAQ_GV-Aview_for_Android.pdf	GV-AView for Android
2013/10/30	GV-Eye and GV-Eye HD for iOS NEW! http://pd.geovision.tw/faq/Remote_Mobile/FAQ_GV-Eye_EyeHD_for_iOS.pdf	GV-Eye and GV-Eye HD for iOS
2013/10/30	GV-Eye for Android NEW! http://pd.geovision.tw/faq/Remote_Mobile/FAQ_GV-Eye_for_Android.pdf	GV-Eye for Android



DVR / NVR Monitoring Software

Date	Title	Applied to
2014/04/07	Why doesn't Live View display when Pelco Spectra IV IP series is connected to GV-System? NEW! http://pd.geovision.tw/faq/MonitoringSW/GV-System_connection_Pelco_Spectra_solution.pdf	GV-System
2014/03/31	Why does the GV-IP Decoder Box / GV-Pad show the "Resolution Error" or "Codec Error" message? NEW! http://pd.geovision.tw/faq/IPCamera/Decoder_box_quad_view_error.pdf	GV-IP Decoder Box / GV-Pad firmware V1.05 or later
2013/09/27	How to upgrade the GeoVision black dongle? http://pd.geovision.tw/faq/MonitoringSW/USB_dongle_upgrade.pdf	GeoVision Black Dongle
2013/07/10	Compatible Antivirus Software with GeoVision Software http://pd.geovision.tw/faq/MonitoringSW/Compatible_antivirus_sw_with_GV.pdf	GeoVision Software
2013/07/05	Why can't I receive the e-mail notice from my Gmail account? http://pd.geovision.tw/faq/IPDevice/Can't_receive_e-mail_notice_from_gmail.pdf	GV-System, GV-Video Server, GV-Compact DVR, GV-IP Camera



2013/06/17	<p>How to add an Axis camera to GV-DVR/NVR through the ONVIF protocol?</p> <p>http://pd.geovision.tw/faq/MonitoringSW/How_to_add_axis_camera_into_GV-DVR-NVR_through_onvif_protocol.pdf</p>	GV-System V8.5.7.0 or later
2013/05/07	<p>How to export the video file with Windows standard codec?</p> <p>http://pd.geovision.tw/faq/MonitoringSW/Exporting_Video_in_Standard_Codec.pdf</p>	GV-System
2013/04/19	<p>How do I create time lapse videos using GV-System or GV-IP Camera?</p> <p>http://pd.geovision.tw/faq/IPCamera/Time_Lapse_Video.pdf</p>	GV-System, GV-IP Camera
2013/04/12	<p>How do I edit the recording path in the GV-System?</p> <p>http://pd.geovision.tw/faq/MonitoringSW/How_do_I_edit_the_recording_path_in_the_GV-System.pdf</p>	GV-System V8.5 or later
2013/01/31	<p>How to load default settings to GV-IP device & GV-System?</p> <p>http://pd.geovision.tw/faq/IPDevice/GVProduct_Load_Default.pdf</p>	GV-System, GV-Video Server, GV-Compact DVR, GV-IP Camera, GV-DSP LPR
2012/12/28	<p>What ONVIF version does GV-System support?</p> <p>http://pd.geovision.tw/faq/MonitoringSW/Supported_ONVIF_Version.pdf</p>	GV-System



2011/12/08	<p>Are GV-NVR and GV-Hybrid DVR ONVIF compliant?</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/GV-System/NVR_HybridDVR_ONVIF.pdf</p>	GV-NVR / GV-Hybrid DVR V8.4 or later
2011/11/17	<p>What is the Remote Playback Server?</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/Main%20System/remove-remote-playback-server.pdf</p>	GV-System earlier than V8.5
2011/11/17	<p>The minimum PC requirements of GV-NVR V8.5</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/Main%20System/NVR-PC-Requirements.pdf</p>	GV-NVR V8.5
2011/11/04	<p>Supported analog PTZ models for GV-System and AUX function</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/IP_device/PTZ-support-GVSystem-AUX.pdf</p>	GV-System V8.5
2011/10/28	<p>What is the arrow icon overlaid on the bottom-right corner of the recordings?</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/Main%20System/arrow-icon-on-recording-j.pdf</p>	GV-System V8.2 or later
2011/10/25	<p>The supported modem models by GeoVision</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/GV-System/supported-modem.pdf</p>	GV-System
2011/08/02	<p>How to remove supervisor accounts from the GV-System?</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/Main%20System/Removing_Supervisor_Account.pdf</p>	GV-System



2011/08/02	<p>How to set up e-mail alerts with Google Gmail?</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/Main%20System/Gmail_EmailAlert.pdf</p>	<p>GV-System V8.3.2 or later</p>
2011/08/02	<p>How to use the RTSP protocol to connect the third-party IP cameras to the GV-System?</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/IP_device/Third-party_IPCam_RTSP.pdf</p>	<p>GV-System, IP Camera</p>
2011/08/02	<p>Can I add multiple IP cameras with a single IP address to the GV-System?</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/IP_device/Adding_IPCam_with_same_IP.pdf</p>	<p>GV-System, GV-IP Camera</p>
2011/08/01	<p>Why can't I get back to the Windows desktop while running the GV-System?</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/Main%20System/Unable_Minimize_Multicam.pdf</p>	<p>GV-System</p>
2011/08/01	<p>Why do the merged video files become jerky after using Advanced Merge?</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/ViewLog/Merge_video_becomes_jerky.pdf</p>	<p>GV-System V8.3.3</p>
2011/07/25	<p>Which PTZ cameras can support Object Tracking?</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/IP_device/PTZ_Tracking_models.pdf</p>	<p>GV-System V8.3.4, V8.4 and V8.5</p>
2011/07/25	<p>What is "Detect Recording Abnormal error"?</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/Main%20System/Unable_To_Write_HDD.pdf</p>	<p>GV-System V8.3.4</p>



2011/07/25	<p>Why does Windows 7 freeze when I start the GV-System?</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/Main%20System/Win7_freeze.pdf</p>	<p>GV-System</p> <p>V8.3.2 or earlier</p>
2011/07/25	<p>Why cannot I see the System Log older than 3 days?</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/Main%20System/Only_load_3days_log_data.pdf</p>	<p>GV-System</p>
2011/07/25	<p>How to merge several AVI files into a single file?</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/Main%20System/How_to_merge_videos.pdf</p>	<p>GV-System</p> <p>V8.4 or later</p>
2011/07/25	<p>Why cannot I add Arecont's IP cameras of 8-megapixel series?</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/Main%20System/Arecont_8M_connection_issue.pdf</p>	<p>GV-System</p> <p>V8.4 or earlier</p>
2011/07/25	<p>How to activate Intrusion Alarm Mode 2 for warning?</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/Main%20System/Intrusion_Mode2_issue.pdf</p>	<p>GV-System</p> <p>V8.4 or earlier</p>
2011/07/25	<p>How to avoid false motion detection when using Object Index?</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/Main%20System/Avoid_false_alarm_in_Object_Index.pdf</p>	<p>GV-System</p> <p>V8.4 or earlier</p>
2010/10/18	<p>How do I know the required hard disk space when recording video files from analog cameras?</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/Main%20System/Analog%20HDD%20calculator-v-j.pdf</p>	<p>GV-System</p>



2010/10/18	<p>Why can't I enable the Startup Auto Login function?</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/Main%20System/auto_login-v-a.pdf</p>	GV-System
2010/10/18	<p>Why aren't the images displayed properly after the screen saver stops, or the computer is in the hibernation or standby mode?</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/Main%20System/screen_saver-v-a.pdf</p>	GV-System
2010/10/18	<p>How to expand the GV-Hybrid DVR to have more IP channels?</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/Hardware/Hybrid_solution_dongle-j.pdf</p>	GV-Hybrid DVR earlier than V8.4
2010/10/14	<p>Is my GV-Video Capture Card compatible with GV-System V8.4?</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/Hardware/card_support_version-a.pdf</p>	GV-System V8.4
2010/10/13	<p>Why does the Directdraw Overlay error message pop up when I start the GV-System?</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/GV-System/Directdraw_fail-a.pdf</p>	GV-System
2010/10/05	<p>What is "DMIPC error" in the System Log?</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/GV-System/DMIPCerror-j.pdf</p>	GV-System
2010/10/05	<p>Why can't I play back the video files on other computers?</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/GV-System/Fail_to_play_back_video-v-a.pdf</p>	GV-System



2010/10/05	I forgot my password. Is there any way to reset it? ftp://geo-demo-japan.dipmap.com/FAQ/GV-System/forget_password.pdf	GV-System V5.3 or later
2010/10/05	How to upgrade GV-System to the latest version? ftp://geo-demo-japan.dipmap.com/FAQ/GV-System/How%20to%20perform%20software%20upgrade-j.pdf	GV-System V8.0 or later
2010/10/05	Why does the Pink Screen show up when I access the GV-System on the second monitor or on the remote desktop? ftp://geo-demo-japan.dipmap.com/FAQ/GV-System/Pink_Screen_Issue-a.pdf	GV-System
2010/10/05	How can I access Main System or ViewLog on the second monitor? ftp://geo-demo-japan.dipmap.com/FAQ/GV-System/Two_mointor-a.pdf	GV-System
2009/06/04	How to embed a digital watermark in the video stream? ftp://geo-demo-japan.dipmap.com/Technotice/GV-System/Watermark_Protection.pdf	GV-System



DVR / NVR System

Date	Title	Applied to
2013/07/05	Why does a warning message appear when running ViewLog on GV-NVR Lite V2? http://pd.geovision.tw/faq/DVR_NVR_System/Warning_msg_appears_when_running_viewlog_on_NVRLiteV2.pdf	GV-NVR Lite V2
2013/02/19	Is there any capacity limit for USB HDD connected to GV-NVR Lite V2? http://pd.geovision.tw/faq/CaptureCard_Accessory/Connecting_external_USB_to_NVR_Lite_V2.pdf	GV-NVR Lite V2

DVR Capture Card, Accessories

Date	Title	Applied to
2014/02/07	Does GV-POE Switch support SFP+? UPDATED! http://pd.geovision.tw/faq/CaptureCard_Accessory/GV-POE_switch_supports_SFP+.pdf	GV-POE Switch
2013/11/12	How do I change the recording resolution when using GV-SDI-204 Cards? NEW! http://pd.geovision.tw/faq/CaptureCard_Accessory/HD-SDI_resolution.pdf	GV-SDI-204 Video Capture Card
2013/11/12	Is it possible for GV-SDI-204 Cards to support audio? NEW! http://pd.geovision.tw/faq/CaptureCard_Accessory/SDI_Card_Audio.pdf	GV-SDI-204 Video Capture Card



2013/09/27	<p>What type of cable can be used for GV-SDI-BX100 Cameras?</p> <p>http://pd.geovision.tw/faq/CaptureCard_Accessory/Cable_type_for_HD_SDI_camera.pdf</p>	GV-SDI-BX100-0 / BX100-1
2013/03/14	<p>What is the voltage range for stable signal of the analog camera connected to GV-Video Capture Card?</p> <p>http://pd.geovision.tw/faq/CaptureCard_Accessory/Analog_camera_input_level_for_capture_card.pdf</p>	GV-Video Capture Card
2013/01/02	<p>Error message "Driver installation failed" after installing GV-Combo Cards in 64-bit OS</p> <p>http://pd.geovision.tw/faq/CaptureCard_Accessory/Error_Message_When_Installing_ComboCard_in_64bitOS.pdf</p>	GV-Video Capture Card (GV-Combo Card)
2012/12/28	<p>Can I increase HD-SDI transmission distance using multiple GV-SDI Repeaters?</p> <p>http://pd.geovision.tw/faq/CaptureCard_Accessory/HD-SDI_Transmission_Over_300ft.pdf</p>	GV-SDI Repeater
2012/12/05	<p>The power consumption of GV-1480A and GV-1480B cards</p> <p>http://pd.geovision.tw/faq/CaptureCard_Accessory/GV1480AB_Power_Consumption.pdf</p>	GV-Video Capture Card (GV-1480 Card)
2011/07/25	<p>Why does my GV-System get low frame rate?</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/Main%20System/Low_frame_rate_caused_by_BIOS.pdf</p>	GV-Combo Card
2011/07/25	<p>Why cannot I install the driver for GV-Keyboard?</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/IP_device/keyboard_not_supporting_Win2003.pdf</p>	GV-Keyboard V3



2010/10/18	How can I expand the GV-System to have more video inputs? ftp://geo-demo-japan.dipmap.com/FAQ/Hardware/capture_card_hardware_upgrade-v-j.pdf	GV-Video Capture Card
2010/10/11	Can GV-Video Capture Card work with other video capture software? ftp://geo-demo-japan.dipmap.com/FAQ/Hardware/Card_other_driver-a.pdf	GV-Video Capture Card
2010/10/05	Which GV-Video Capture Card can support two-card mode? ftp://geo-demo-japan.dipmap.com/FAQ/GV-System/Two_cards_suppport-j.pdf	GV-Video Capture Card
2010/10/05	Which GV-Video Capture Card can support Windows 7? ftp://geo-demo-japan.dipmap.com/FAQ/GV-System/Windows7_Support-j.pdf	GV-Video Capture Card



DVR / NVR Playback

Date	Title	Applied to
2014/02/10	How do I run Remote ViewLog using a non-administrator account? NEW! http://pd.geovision.tw/faq/Playback/Running_Remote_ViewLog_using_non-admin_account.pdf	Remote ViewLog V8.5.7 or later
2013/08/09	How do I move Remote ViewLog window to another monitor? http://pd.geovision.tw/faq/Remote_Mobile/Remote_ViewLog.pdf	GV-Remote ViewLog V.8.3.2.0 or later
2013/06/14	Why a small arrow icon appears on ViewLog and how to avoid it? http://pd.geovision.tw/faq/Playback/Why_a_small_arrow_icon_appears_on_viewlog_&_how_to_avoid_it.pdf	GV-System V8.2.0.0 or later
2011/11/17	What is the Remote Playback Server? ftp://geo-demo-japan.dipmap.com/FAQ/Main%20System/remove-remote-playback-server.pdf	GV-System earlier than V8.5
2011/07/25	Why cannot I access Remote Playback using the domain name obtained from DDNS? ftp://geo-demo-japan.dipmap.com/FAQ/Webcam/WebCam_RPB_not_working_with_Dipmap.pdf	GV-System V8.3.4
2010/11/05	Why do I get green screen when running Remote Playback? ftp://geo-demo-japan.dipmap.com/FAQ/Webcam/Remote_Playback_Green_Screen-j.pdf	GV-System



2010/10/18	How can I play back the files on a DVD player? ftp://geo-demo-japan.dipmap.com/FAQ/ViewLog/export_to_DVD-a.pdf	GV-System V8.3.2 or earlier
2010/10/18	Why can't I play back video files on Mac OS? ftp://geo-demo-japan.dipmap.com/FAQ/Webcam/Video%20File%20Playback%20on%20Mac-i.pdf	Mac OS
2010/10/12	Why does the "Decoder not found" error message pop up when I try to play back the videos using Remote Playback? ftp://geo-demo-japan.dipmap.com/FAQ/Webcam/Decoder_not_found-a.pdf	GV-System V8.2 or earlier

Remote / Mobile Viewing

Date	Title	Applied to
2014/03/07	How do I connect GV-SD200 with Multi View (DMMultiView)? NEW! http://pd.geovision.tw/faq/Remote_Mobile/Connecting_GV-SD200_with_MultiView.pdf	GV-Multi View
2014/02/10	How do I run Remote ViewLog using a non-administrator account? NEW! http://pd.geovision.tw/faq/Playback/Running_Remote_ViewLog_using_non-admin_account.pdf	Remote ViewLog V8.5.7 or later
2014/01/03	Why can't I access live view on GV-Mobile Server using Chrome and Firefox? NEW! http://pd.geovision.tw/faq/Remote_Mobile/MobileServer_Chrome_Firefox_Issue.pdf	GV-Mobile Server V1.3 - V1.4.1



2013/11/28	How do I delete the connection history of Remote ViewLog? NEW! http://pd.geovision.tw/faq/Remote_Mobile/RemoteViewLog_Delete_History.pdf	Remote ViewLog
2013/11/01	GV-iView and GV-iView HD for iOS NEW! http://pd.geovision.tw/faq/Remote_Mobile/FAQ_GV-iView_iViewHD_for_iOS.pdf	GV-iView and GV-iView HD
2013/11/01	GV-AView for Android NEW! http://pd.geovision.tw/faq/Remote_Mobile/FAQ_GV-Aview_for_Android.pdf	GV-AView for Android
2013/10/30	GV-Eye and GV-Eye HD for iOS NEW! http://pd.geovision.tw/faq/Remote_Mobile/FAQ_GV-Eye_EyeHD_for_iOS.pdf	GV-Eye and GV-Eye HD for iOS
2013/10/30	GV-Eye for Android NEW! http://pd.geovision.tw/faq/Remote_Mobile/FAQ_GV-Eye_for_Android.pdf	GV-Eye for Android
2013/09/12	Why can't I connect the GV-Recording Server V1.2.0.0 using the GV-Remote ViewLog V8.5.7.0? http://pd.geovision.tw/faq/Remote_Mobile/RSv12_remote_viewlogv8570.pdf	GV-Recording Server V1.2.0.0
2013/09/06	Does GV-Eye support dual streams when connecting to a GV-IP Camera? http://pd.geovision.tw/faq/Remote_Mobile/GV-EYE_stream_switch.pdf	GV-Mobile Application (GV-Eye)



2013/05/08	How many channels does a GV-DVR/NVR support for remote viewing? http://pd.geovision.tw/faq/Remote_Mobile/How_many_channels_GV-DVR-NVR_support_for_remote_viewing.pdf	GV-System
2013/04/01	How to authorize the channels for GV-Mobile Application' users? http://pd.geovision.tw/faq/Remote_Mobile/Authorizing_channels_for_GV-Mobile_Applications'_users.pdf	GV-Mobile Application
2013/03/28	Can I see de-warped GV-Fisheye images from my cell phone? http://pd.geovision.tw/faq/Remote_Mobile/Can_I_see_dewarped_fisheye_images_from_Cellphone.pdf	GV-Mobile Application
2013/03/07	How do I export the address book of GV-iView from one iOS device to another? http://pd.geovision.tw/faq/Remote_Mobile/Exporting_address_book_of_GV-iView.pdf	GV-Mobile Application (GV-iView/iView HD)
2013/03/04	Why does the Resolution Error message pop up in Multi View? http://pd.geovision.tw/faq/MonitoringSW/Resolution_Error_Message_MultiView.pdf	GV-Multi View
2011/12/01	How to enable Fisheye dewarping function on WebCam Server, Multi Viewer and Center V2? ftp://geo-demo-japan.dipmap.com/FAQ/Webcam/Fisheye_dewarping_on_WebCam_CV2_MultiView.pdf	GV-WebCam Server GV-Multi View GV-Center V2
2011/07/25	How to display text stamps in 16 / 32 screen divisions in Multi View? ftp://geo-demo-japan.dipmap.com/FAQ/Webcam/Enable_MultiView_stamp_in_16_and_32_divisions.pdf	GV-Multi View



2011/07/25	Why cannot I access Remote Playback using the domain name obtained from DDNS? ftp://geo-demo-japan.dipmap.com/FAQ/Webcam/WebCam_RPB_not_working_with_Dipmap.pdf	GV-System V8.3.4
2011/04/19	How to Set up Webcam FTP Server? ftp://geo-demo-japan.dipmap.com/FAQ/Webcam/FTP%20setup.pdf	GV-System
2010/11/08	How to disable the recording function of the live view on the Webcam Server? ftp://geo-demo-japan.dipmap.com/FAQ/Webcam/Webcam_recording_disable-a-revised3.pdf	GV-System V8.0 or later
2010/11/05	Why do I get green screen when running Remote Playback? ftp://geo-demo-japan.dipmap.com/FAQ/Webcam/Remote_Playback_Green_Screen-j.pdf	GV-System
2010/10/18	How to configure the port forwarding to allow remote viewing? ftp://geo-demo-japan.dipmap.com/FAQ/Webcam/port_forward-v-a.pdf	GV-System
2010/10/18	How can I access live view using iPhone or iPod Touch? ftp://geo-demo-japan.dipmap.com/FAQ/Webcam/iPhone-j.pdf	GV-Mobile Application
2010/10/13	Why can't I remotely access live view on Mac OS X? ftp://geo-demo-japan.dipmap.com/FAQ/Webcam/Access_live_video_on_Mac-a.pdf	MAC OS X 10.5



2010/10/13	Can I access live view through Safari, Firefox or Google Chrome? ftp://geo-demo-japan.dipmap.com/FAQ/Webcam/Remote_viewing_using_other_browsers-j.pdf	GV-System
2010/10/12	Why does the “Decoder not found” error message pop up when I try to play back the videos using Remote Playback? ftp://geo-demo-japan.dipmap.com/FAQ/Webcam/Decoder_not_found-a.pdf	GV-System V8.2 or earlier
2010/10/11	What application can I use for remote viewing on Windows 7? ftp://geo-demo-japan.dipmap.com/FAQ/Webcam/Remote%20viewing%20support-a.pdf	GV-System V8.3.3 or later

Retail Solution, POS Integration		
Date	Title	Applied to
2013/04/15	What type of GV-POS integration is supported? http://pd.geovision.tw/faq/POS/What_type_of_GV-POS_integration_is_supported.pdf	GV-Data Capture Box, GV-POS Text Sender
2013/03/04	Is it possible to receive POS without any camera connected in GV-System? http://pd.geovision.tw/faq/POS/Receiving_POS_without_Camera_Connected.pdf	GV-System
2012/12/03	Where can I find the latest firmware release for GeoVision products? http://pd.geovision.tw/faq/IPDevice/Where_can_I_find_latest_firmware.pdf	All GeoVision products requiring firmware upgrade



2010/12/08	Why my GV-System can't detect the POS Text Sender dongle? ftp://geo-demo-japan.dipmap.com/FAQ/POS/POS_Text_Sender-j.pdf	GV-System earlier than V8.4, GV-POS Text Sender
2010/10/18	Why can't I see the POS data on the GV-System? ftp://geo-demo-japan.dipmap.com/FAQ/POS/POS_No_Data-a.pdf	GV-System V8.3.1 or later

IP Devices (GV-IP Camera, GV-Video Server, GV-Compact DVR)

Date	Title	Applied to
2013/07/05	Why can't I receive the e-mail notice from my Gmail account? http://pd.geovision.tw/faq/IPDevice/Can't_receive_e-mail_notice_from_gmail.pdf	GV-System GV-Video Server GV-Compact DVR GV-IP Camera
2013/04/15	Which GV-Video Server supports 4G network? http://pd.geovision.tw/faq/VideoServer_CompactDVR/Which_GV-Video_Server_supports_4G_network.pdf	GV-Video Server
2013/03/04	Can I acquire GPS data of GV-IP Devices from third-party software? http://pd.geovision.tw/faq/IPDevice/GPS_Data_Export_Support.pdf	GV-Video Server GV-Compact DVR
2013/03/04	How do I connect an external alarm device to GV-IP Devices? http://pd.geovision.tw/faq/IPDevice/Connect_external_alarm_to_GV-IPDevice.pdf	GV-Video Server GV-Compact DVR GV-IP Camera



2013/02/27	Where can I find a player to play back files created by GV-IP Device? http://pd.geovision.tw/faq/IPDevice/PlayingBack_files_created_by%20GV-IP_Device.pdf	GV-Video Server GV-Compact DVR GV-IP Camera
2013/02/27	Why can't I access my GV-IP Device from the Internet? http://pd.geovision.tw/faq/IPCamera/Access_IPCamera_from_Internet_Port_Forwarding.pdf	GV-Video Server GV-Compact DVR GV-IP Camera
2013/02/26	How do I know the dynamic IP address of GV-IP Devices when using DHCP? http://pd.geovision.tw/faq/IPDevice/Dynamic_IP_Address_Device_Utility.pdf	GV-Video Server GV-Compact DVR GV-IP Camera
2013/02/26	What's the maximum number of streams supported for GV-IP devices? http://pd.geovision.tw/faq/IPDevice/Maximum_Number_Streams_IPDevice.pdf	GV-Video Server GV-Compact DVR GV-IP Camera
2013/02/26	How to use GV-IP Device Utility to upgrade firmware and manage multiple GV-IP Devices simultaneously? http://pd.geovision.tw/faq/IPDevice/IPDeviceUtility_Batch_Management.pdf	GV-Video Server GV-Compact DVR GV-IP Camera
2013/02/07	How do I export my configuration from one GV-IP device to another? http://pd.geovision.tw/faq/IPDevice/How_to_export_GVIPDevice_Settings.pdf	GV-Video Server GV-Compact DVR GV-IP Camera
2013/02/06	What is the Dynamic DNS Server (DDNS)? http://pd.geovision.tw/faq/IPDevice/What_is_DDNS.pdf	GV-Video Server GV-Compact DVR GV-IP Camera
2013/02/05	Where can I find the password for my GV-IP Device? http://pd.geovision.tw/faq/IPDevice/GV-IPDevices_Password.pdf	GV-Video Server GV-Compact DVR GV-IP Camera



2013/02/05	<p>Installing GeoVision OCX when accessing Web interface of GV-IP Devices</p> <p>http://pd.geovision.tw/faq/IPDevice/IPDevice_Installing_GeoVisionOCX.pdf</p>	<p>GV-Video Server GV-Compact DVR GV-IP Camera</p>
2013/02/01	<p>Is daylight savings time supported in GV-IP device?</p> <p>http://pd.geovision.tw/faq/IPDevice/GVIPDevice_Support_Daylight_Savings_Time.pdf</p>	<p>GV-Video Server GV-Compact DVR GV-IP Camera</p>
2013/01/31	<p>How to load default settings to GV-IP device & GV-System?</p> <p>http://pd.geovision.tw/faq/IPDevice/GVProduct_Load_Default.pdf</p>	<p>GV-System, GV-Video Server GV-Compact DVR GV-IP Camera</p>
2013/01/02	<p>How do I upgrade the firmware on GV-IP Device?</p> <p>http://pd.geovision.tw/faq/IPDevice/How_to_upgrade_firmware.pdf</p>	<p>GV-Video Server GV-Compact DVR GV-IP Camera</p>
2012/12/25	<p>Can GV-System, GV-Center V2 and GV-VSM receive notifications for tampering events from GV-IP Camera or GV-Video Server?</p> <p>http://pd.geovision.tw/faq/IPDevice/tampering_alarm_notification.pdf</p>	<p>GV-Video Server GV-IP Camera</p>
2012/12/21	<p>How do I configure the bit rate and what are the effects?</p> <p>http://pd.geovision.tw/faq/IPDevice/bit_rates_settings.pdf</p>	<p>GV-Video Server GV-Compact DVR GV-IP Camera</p>



2012/12/21	<p>How do I change the HTTP and VSS port settings?</p> <p>http://pd.geovision.tw/faq/IPDevice/Change_HTTP_VSS_ports.pdf</p>	<p>GV-Video Server GV-Compact DVR GV-IP Camera</p>
2012/12/20	<p>How do I change the live view orientation?</p> <p>http://pd.geovision.tw/faq/IPDevice/Change_image_orientation.pdf</p>	<p>GV-Video Server GV-Compact DVR GV-IP Camera</p>
2012/12/05	<p>How can I assign a static IP address to my GeoVision IP Camera/Video Server/Compact DVR?</p> <p>http://pd.geovision.tw/faq/IPCamera/Supported_Web_Browser.pdf</p>	<p>GV-Video Server GV-Compact DVR GV-IP Camera</p>
2011/10/28	<p>How to send a sequence of snapshot images to the FTP server for alerts?</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/IP_device/FTP-continuous-snapshot.pdf</p>	<p>GV-Video Server GV-Compact DVR GV-IP Camera</p>
2010/11/08	<p>How do I use the RTSP protocol to connect GV IP devices?</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/IP_device/RTSP_protocol-j_revised6.pdf</p>	<p>GV-Video Server GV-Compact DVR GV-IP Camera</p>



IP Camera Only		
Date	Title	Applied to
2014/03/31	Why does the GV-IP Decoder Box / GV-Pad show the “Resolution Error” or “Codec Error” message? NEW! http://pd.geovision.tw/faq/IPCamera/Decoder_box_quad_view_error.pdf	GV-IP Decoder Box / GV-Pad firmware V1.05 or later
2014/03/28	How to solve GV-IP Camera light flicker issue? NEW! http://pd.geovision.tw/faq/IPCamera/GV-IP_Camera_light_flicker_solution.pdf	GV-IP Camera
2014/02/07	The maximum power consumption of GV-IP Cameras UPDATED! http://pd.geovision.tw/faq/IPCamera/IPCAM_Power_consumption.pdf	GV-IP Camera
2014/02/07	The supported power types for GV-IP Cameras UPDATED! http://pd.geovision.tw/faq/IPDevice/Supported_IPCAM_Power.pdf	GV-IP Camera
2014/02/07	Does GV-POE Switch support SFP+? UPDATED! http://pd.geovision.tw/faq/CaptureCard_Accessory/GV-POE_switch_supports_SFP+.pdf	GV-POE Switch
2014/01/09	Why does the GV-IP camera’s 320 x 240 image not fill up the TV monitoring screen? NEW! http://pd.geovision.tw/faq/IPCamera/IPCam_320x240_image_not_fill_up_TV_screen.pdf	GV-BX, GV-BX-E, GV-VD and GV-FD Series



2014/01/08	<p>Why does the GV-UBL Camera show a white circular image during night surveillance? NEW!</p> <p>http://pd.geovision.tw/faq/IPCamera/UBLCam_show_a_white_circular_image_at_night.pdf</p>	GV-UBL Series
2013/12/04	<p>Which GV-IP Cameras support recording of 1920 x 1080 at 25 fps? NEW!</p> <p>http://pd.geovision.tw/faq/IPCamera/IPCam_support_full_HD_recording_25fps.pdf</p>	GV-IP Camera
2013/11/19	<p>Which brands of wireless access points have been tested for GeoVision wireless cameras? NEW!</p> <p>http://pd.geovision.tw/faq/IPCamera/Tested_Wireless_Access_Point.pdf</p>	<p>GV-BX1200 Series / 1300 Series / 1500 Series / 2400 Series / 3400 Series / 5300 Series, GV-CAW120 / 220, GV-CBW120 / 220, GV-MFD1501 Series / 2401 Series / 3401 Series / 5301 Series</p>
2013/09/27	<p>How to download the video from the Micro SD card in the GV-IP camera?</p> <p>http://pd.geovision.tw/faq/IPCamera/Download_files_from_SD_card_on_ip_camera.pdf</p>	GV-IP Camera firmware V1.11 or later
2013/08/09	<p>How to Upgrade a GV-Fisheye Camera from Firmware Earlier than V2.02 to Firmware V2.03 or later?</p> <p>http://pd.geovision.tw/faq/IPCamera/Upgrading_Fisheye.pdf</p>	GV-Fisheye Camera



2013/08/09	<p>What are the supported SNMP commands in GV-IP Camera?</p> <p>http://pd.geovision.tw/faq/IPCamera/Supported_SNMP_Commands.pdf</p>	<p>GV-IP Camera firmware V1.03 or later</p>
2013/08/06	<p>Why can't I access the third-party IP Camera with GV-IP Decoder Box?</p> <p>http://pd.geovision.tw/faq/IPCamera/Cannot%20see%20my%203rd%20party%20IP%20camera%20on%20GV%20ip%20decoder%20box.pdf</p>	<p>GV-IP Decoder Box</p>
2013/07/05	<p>Why can't I receive the e-mail notice from my Gmail account?</p> <p>http://pd.geovision.tw/faq/IPDevice/Can't_receive_e-mail_notice_from_gmail.pdf</p>	<p>GV-System GV-Compact DVR GV-Video Server GV-IP Camera</p>
2013/06/17	<p>How to set up Recording Schedule on the GV-IP Camera?</p> <p>http://pd.geovision.tw/faq/IPCamera/How_to_set_up_recording_schedule_on_gv-ip_cameras.pdf</p>	<p>GV-IP Camera</p>
2013/05/07	<p>How to rewire a standard Ethernet cable for GV-IP Camera?</p> <p>http://pd.geovision.tw/faq/IPCamera/GV-IPCam_RJ45_Cable_chart.pdf</p>	<p>GV-IP Camera</p>
2013/04/19	<p>How do I create time lapse videos using GV-System or GV-IP Camera?</p> <p>http://pd.geovision.tw/faq/IPCamera/Time_Lapse_Video.pdf</p>	<p>GV-System GV-IP Camera</p>
2013/04/03	<p>Can I upgrade GV-SD200 by using GV-IP Device Utility?</p> <p>http://pd.geovision.tw/faq/IPCamera/Can_I_upgrade_GV-200_using_GV-IP_Device_Utility.pdf</p>	<p>GV-SD200</p>



2013/01/31	How do I manage and calculate the bandwidth usage of GV-IP Cameras? http://pd.geovision.tw/faq/IPCamera/Bandwidth_Management_and_Calculation.pdf	GV-IP Camera
2013/01/31	Why does my GV-IP Camera automatically turn black and white in low light conditions? http://pd.geovision.tw/faq/IPCamera/GVIPDeivce_Switch_to_BlackWhite_DNMode.pdf	GV-IP Camera
2012/12/25	Does GV-SD200 support authentication when connecting through RTSP? http://pd.geovision.tw/faq/IPCamera/Authentication_Support_for_GVSD200.pdf	GV-SD200
2012/12/25	Is PoE supported for GV-SD200-S? http://pd.geovision.tw/faq/IPCamera/PoE_Support_for_GVSD200S.pdf	GV-SD200
2012/12/19	The Supported Web Browsers by GV-IP Camera. http://pd.geovision.tw/faq/IPCamera/Supported_Web_Browser.pdf	GV-IP Camera
2012/12/05	How to enable digital zoom in SD200? http://pd.geovision.tw/faq/IPCamera/Enable_digital_zoom_on_SD200.pdf	GV-SD200
2012/12/05	GV-SD200 cannot perform digital zoom after firmware upgrade http://pd.geovision.tw/faq/IPCamera/Cannot_zoom_after_firmware_upgrade_of_SD200.pdf	GV-SD200 firmware V1.01



2012/12/04	The IR LED in Bullet Camera http://pd.geovision.tw/faq/IPCamera/Gaps_on_Bullet_Camera_IR_LED.pdf	GV-BL110D / 120D / 220D / 320D
2012/12/03	Can I turn off the Status LED on GeoVision Box Camera? http://pd.geovision.tw/faq/IPCamera/Turn_off_status_LED_on_Box_Camera.pdf	GV-Box Camera
2012/11/29	Why is there a part of image being cut off in FE520? http://pd.geovision.tw/faq/IPCamera/Missing_Parts_on_5MP_Fisheye_View.pdf	GV-FE520
2011/08/02	Can I add multiple IP cameras with a single IP address to the GV-System? ftp://geo-demo-japan.dipmap.com/FAQ/IP_device/Adding_IPCam_with_same_IP.pdf	GV-System, GV-IP Camera
2011/08/02	How to use the RTSP protocol to connect the third-party IP cameras to the GV-System? ftp://geo-demo-japan.dipmap.com/FAQ/IP_device/Third-party_IPCam_RTSP.pdf	GV-System, IP Camera
2011/07/25	How to enable live audio of GV-BX110D on GV-System? ftp://geo-demo-japan.dipmap.com/FAQ/IP_device/Enable_Audio_between_BX110D_and_DVR.pdf	GV-BX110D
2011/07/25	How to acquire the camera's RTSP link? ftp://geo-demo-japan.dipmap.com/FAQ/IP_device/acquire_RTSP.pdf	GV-IP Camera



2011/07/25	Can I use any battery to power up GV-IP cameras? ftp://geo-demo-japan.dipmap.com/FAQ/IP_device/Battery_for_IPCAM.pdf	GV-IP Camera
2010/10/18	How to add GV-BL110D to GV-System V8.3.4? ftp://geo-demo-japan.dipmap.com/FAQ/IP_device/Bullet_IPCAM-i.pdf	GV-BL110D

CMS		
Date	Title	Applied to
2014/04/07	Why does an “Entry Point Not Found” message appear in GV-Dispatch Server? NEW! http://pd.geovision.tw/faq/CMS/GV-Dispatch_Server_XP_message_solution.pdf	GV-Dispatch Server V8.5.9 or later
2013/07/10	Compatible Antivirus Software with GeoVision Software http://pd.geovision.tw/faq/MonitoringSW/Compatible_antivirus_sw_with_GV.pdf	GeoVision Software
2013/07/05	Why does it show “Video Not Updated” on GV-Control Center’s Matrix view? http://pd.geovision.tw/faq/CMS/Video_not_updated_on_control_center's_matrix_view.pdf	GV-Control Center V3.0 or later
2013/03/14	Why does the font of mobile host name become bold in GV-GIS? http://pd.geovision.tw/faq/CMS/GIS_host_name_in_bold_instead_of_plain.pdf	GV-GIS



2013/03/06	How can I choose which camera to send to Center V2 when Motion Detection triggers? http://pd.geovision.tw/faq/CMS/Sending_Cameras_to_CenterV2_upon_Motion_Detection.pdf	GV-Center V2
2012/12/04	Why is Center V2 recording video file in different time from the PC? http://pd.geovision.tw/faq/CMS/Video_Time_CenterV2.pdf	GV-Center V2
2011/12/01	How to enable Fisheye dewarping function on WebCam Server, Multi Viewer and Center V2? ftp://geo-demo-japan.dipmap.com/FAQ/Webcam/Fisheye_dewarping_on_WebCam_CV2_MultiView.pdf	GV-WebCam Server, GV-Multi View, GV-Center V2



Access Control and LPR

Date	Title	Applied to
2014/02/06	LPR images captured from GV-Video Server and GV-Compact DVR appear interlaced NEW! http://pd.geovision.tw/faq/AccessControl/Interlaced_LPR_Image_from_Standalone.pdf	GV-ASManager V4.0 GV-DVR LPR GV-Compact DVR GV-Video Server
2013/11/13	Which countries' license plates are supported by GeoVision LPR system? NEW! http://pd.geovision.tw/faq/AccessControl/LPR_plates_supported_country.pdf	GV-DVR LPR software, GV-DSP LPR V3 firmware
2013/05/08	Why can't I save the GV-AS Controller's Web settings? ftp://geo-demo-japan.dipmap.com/FAQ/LPR/DSP_LPR/How_to_Superimpose_Recognized_Plate_Numbers_on_DVR_Screen.pdf	GV-AS Controller
2013/05/08	How does GV-LPR Camera work during the day and the night? http://pd.geovision.tw/faq/AccessControl/How_does_GV-LPR_camera_work_during_the_day_and_the_night.pdf	GV-LPR Camera
2013/04/12	Can GV-AS ID F Card & F Tag be applied to GV-Reader? http://pd.geovision.tw/faq/AccessControl/Can_GV-AS_ID_F_Card_Tag_be_applied_to_GV-Reader.pdf	GV-AS ID Card & Tag



2013/04/11	<p>How to back up the database of the GV-ASManager?</p> <p>http://pd.geovision.tw/faq/AccessControl/How_to_back_up_the_database_of_GV-ASManager.pdf</p>	<p>GV-ASManager V3.0 or later</p>
2013/04/03	<p>Firmware & software compatibility for Access Control & LPR</p> <p>http://pd.geovision.tw/faq/AccessControl/Firmware_software_compatibility_Access_Control_LPR.pdf</p>	<p>GV-ASManager GV-AS Controller GV-DSP LPR Camera</p>
2013/03/14	<p>Does GV LPR camera use visible or invisible IR LED lights?</p> <p>http://pd.geovision.tw/faq/AccessControl/LPR_cam_IR_LED_question.pdf</p>	<p>GV-LPR CAM GV-Hybrid LPR Camera</p>
2012/12/25	<p>How do I delete fingerprint data from GV-GF Fingerprint Readers?</p> <p>http://pd.geovision.tw/faq/AccessControl/Delete_Fingerprint_from_Fingerprint_Readers.pdf</p>	<p>GV-GF Fingerprint Readers</p>
2012/12/03	<p>Where can I find the latest firmware release for GeoVision products?</p> <p>http://pd.geovision.tw/faq/IPDevice/Where_can_I_find_latest_firmware.pdf</p>	<p>All GeoVision products requiring firmware upgrade</p>
2011/10/06	<p>What is "Disconnected (xxx) error" in the Device View?</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/AS%20Controller/ASManager_error_message.pdf</p>	<p>GV-ASManager</p>
2011/07/25	<p>Why cannot GV-AS400 Controller reconnect to readers after recovering from a power shutdown?</p> <p>ftp://geo-demo-japan.dipmap.com/FAQ/AS%20Controller/AS400_not_remembering_settings_after_poweroff.pdf</p>	<p>GV-AS400</p>



2010/11/15	GV-LPR Feature Guide V3.1.2.1 ftp://geo-demo-japan.dipmap.com/FAQ/LPR/LPR/V3121.GV-LPR_Feature_Guide.pdf	GV-LPR System V3.1.2.1
2010/11/15	GV-LPR Guide for Qualified Image Criteria ftp://geo-demo-japan.dipmap.com/FAQ/LPR/LPR/QG_LPR.pdf	GV-LPR System
2010/11/09	Assigning the Alarm Group to the Registered Vehicle ftp://geo-demo-japan.dipmap.com/FAQ/LPR/LPR/Assign_Alarm_Group.pdf	GV-LPR System
2010/11/09	How to Use Remote ViewLog to Play Back the Video Recordings from GV-Series DVR in GV-LPR? ftp://geo-demo-japan.dipmap.com/FAQ/LPR/LPR/How_to_use_Remote_ViewLog.pdf	GV-LPR System
2010/11/09	How to Import Excel Database to GV-LPR System? ftp://geo-demo-japan.dipmap.com/FAQ/LPR/LPR/Import_Excel_Database.pdf	GV-LPR System
2010/11/09	Setting the GV-System to start in ahead of the GV-LPR System ftp://geo-demo-japan.dipmap.com/FAQ/LPR/LPR/LPRPilot.exe.pdf	GV-LPR System
2010/11/09	How to Sync SQL and LPR Database? ftp://geo-demo-japan.dipmap.com/FAQ/LPR/LPR/Sync_SQL_Database.pdf	GV-LPR System



2010/11/09	How to overlay Vehicle IDs on the images of GV-DVR? ftp://geo-demo-japan.dipmap.com/FAQ/LPR/LPR/overlay_VehicleID_DVR.pdf	GV-LPR System
2010/11/09	How to query database from a remote site? ftp://geo-demo-japan.dipmap.com/FAQ/LPR/LPR/Remote_RecogDB.pdf	GV-LPR System
2010/11/09	Resetting Resolution on GV-DVR V8.31 for GV-LPR V3.1 ftp://geo-demo-japan.dipmap.com/FAQ/LPR/LPR/LPR_DVR_Resolution_Setting.pdf	GV-LPR System
2010/11/09	Video playback from GV-Compact DVR and GV-Video Server ftp://geo-demo-jaan.dipmap.com/FAQ/LPR/LPR/ComactDVR_VideoServer_Playback.pdf	GV-LPR System
2010/11/09	How to access GV-DSP LPR V2's SD card information via FTP? ftp://geo-demo-japan.dipmap.com/FAQ/LPR/DSP_LPR/Access_DSPLPR_SD_via_FTP.pdf	GV-DSP LPR V2
2010/11/09	How to connect the Output Device from GV-DSP LPR to GV-LPR System? ftp://geo-demo-japan.dipmap.com/FAQ/LPR/DSP_LPR/Access_DSPLPR_SD_via_FTP.pdf	GV-DSP LPR V2
2010/11/09	How to Superimpose the Recognized Plate Numbers from GV-DSP LPR on GV-Series DVR Screen? ftp://geo-demo-japan.dipmap.com/FAQ/LPR/DSP_LPR/How_to_Superimopse_Recognized_Plate_Numbers_on_DVR_Screen.pdf	GV-DSP LPR V2



Digital Signage

Date	Title	Applied to
2013/07/05	Comparison Chart of GV-CMS Server & GV-CMS Lite http://pd.geovision.tw/faq/Digital_Signage/Comparison_chart_of_CMS_server_&_CMS_lite.pdf	GV-CMS Lite V1.0.2.0 GV-CMS Server V1.0.2.0

For All GeoVision Products

Date	Title	Applied to
2013/02/26	What is the maximum length of Ethernet CAT5 cable when connecting with GeoVision products? http://pd.geovision.tw/faq/MonitoringSW/Cat5_Maximum_Cable_Length.pdf	GeoVision Products
2012/12/03	Where can I find the latest firmware for GeoVision products? http://pd.geovision.tw/faq/IPDevice/Where_can_I_find_latest_firmware.pdf	GeoVision Products