

GV-NET Card


The GV-NET Card is a RS-485 / RS-232 interface converter that can be installed inside a PC.

Installation

Insert the GV-NET card to an empty card slot. Connect one of the PC power supply's 4 pins-mini cable to the GV-NET card's power input connector.

Packing List


- 1 GV-NET Card x1
- 2 RJ-11 to DB9 Cable x1
- 3 4pins to 4pins Mini Power Cable x 1



Specification

Communication	RS-485 1,200~19,200 bps
DC IN	DC 5V, 1A
Environmental Condition	0 to 50 degree C , 5%~95% (non-condensing)
Compatible Models	All GV-Models

Connecting RS-485 Devices (GV-IO)



Connecting RS-485 Devices (PTZ Dome)

