


# ZONEC2

## Zone Controller 2

### Zone Controller 2 Overview

Advanced Network Device's (AND) devices are Power over Ethernet (PoE, PoE+) and require only an RJ-45 connector to connect to existing data networks. You can broadcast simultaneously to both phones and speakers. When you implement an AND zone controller you can connect to your existing amplifier, making your existing analog speakers IP enabled.



### Features

#### Built in Web Server:

- Configurable volume
- Device status
- Field upgradable

#### Easy Installation:

- Only requires CAT 5 connection to network, up to 300 ft.
- Power over Ethernet

#### Interfaces:

- Unbalanced line level audio in/out via RCA connectors
- Line Out power level is up to 2 Vpp
- 2 general purpose inputs
- 1 general purpose output with option to provide 12V DC power
- 8-ohm speaker output
- Microphone input

#### Multicast:

- Full multicast and broadcast support. Send audio to individual devices, all devices or groups of devices.


#### Sound Masking:

- Generate configurable pink noise programmatically.


#### Options:

- Wall mount option included


Terminal Connection Detail




Top




Side



Front



Side



Back

