



## Comparison Chart for GV-Edge Recording Manager Versions

Software Functions	Windows Version	Mac Version
<b>Camera &amp; Host Settings</b>		
Enable/Disable Camera Monitoring	Yes	Yes
Camera/Host Auto-Scanning	Yes	Yes
Camera IP Auto-Assigning	Yes	Yes
ID/Password Setting	Yes	Yes
Information Display (MAC address, F/W Version, Model)	Yes	N/A
Device Name	Yes	Yes
Support for Authentication Server <sup>1</sup>	Yes	N/A
Output Trigger	Yes	N/A
<b>Live View</b>		
PTZ Control	Yes	Yes (Auto Pan functions not supported)
Recording Status Indicator (Monitoring / Non-monitoring)	Yes	Yes
Max. Number of Channels	64	32
Channel	Free	4, 6, 8, 9, 10, 13, 16, 25, 36
Division	With GV-USB Dongle	4, 6, 8, 9, 10, 13, 16, 25, 36, 49, 64
Customized Division Layout	Yes	N/A
Image Drag and Drop	N/A	Yes
Image Rotation (0°, 90°, 180°, 270°)	N/A	Yes
Snapshot	Yes	Yes
Viewing Options (PIP view, PAP view, Wide Angle)	Yes	N/A
Screen Setting (Fitting Window / Fixed Ratio change)	Yes	Yes
Fisheye Dewarping	Yes	Yes (Object Track, Auto Pan and Guard Tour Setting not supported)
Audio	2-way	1-way
On-Demand (Dual Streaming)	Yes	Yes
Fisheye Dual Streaming	Yes	N/A
Saving Layout from Different Hosts	Yes	N/A
Corridor-Mode Live View Display	Yes	N/A
QView Display <sup>2</sup>	Yes	N/A
Support for GV-VMS Heat Map analysis	Yes	N/A
Support for H.265 Codec	Yes	N/A
Displaying channels from GV-VMS Trial version	Yes	N/A
<b>Playback</b>		
Timeline Mode	N/A	Yes
Max. Number of Channels	1	1
Play Speed <sup>3</sup>	Yes	N/A
Remote ViewLog Player <sup>4</sup>	Yes	N/A
<b>NAS Settings</b>		
NAS Setup (Path, ID/Password, Search)	Yes	Yes
Storage Information	Yes	Yes



NAS / SNVR Playback		
Video Clip Download	Yes	N/A
Video Analytics Playback (Fisheye Dewarp, Defog, Stabilizer)	Yes	N/A
Supported Hosts		
For Windows	GV-IP Camera, GV-Video Server (VS11, VS12, VS14, VS2400/2420), GV-System (GV-DVR/NVR), GV-VMS, GV-Recording Server, GV-SNVR	
For Mac OS X	GV-IP Camera, GV-Video Server (VS11, VS12, VS14), GV-VMS, GV-Recording Server	

All specifications are subject to change without notice.

**Note:**

1. GV-Edge Recording Manager can integrate with the Authentication Server to perform live view and playback of the devices under a specified GV-VMS or GV-System account.
2. QView Display enables the projection of a live view display onto one other monitor.
3. The Play Speed option is not supported in GV-SNVR.
4. A maximum of 16 channels can be supported in the Remote ViewLog Player.