



CLEAR SERIES PUSH NOTIFICATIONS SETUP GUIDE

Enabling Push Notifications

CLR-XVR/NVR Setup


beforehand if you wish to utilize these features within the push notification section of the

Note: Make sure to setup and enable any of the alarm features on your CLR device CLEAR VMS application.


1. Hook up your CLEAR device to your display monitor and login to your administrator
2. Go to the Main Menu and select "Alarm".




3. Within the "Event Notification" tab located in the top right corner of the page select the option labeled "Push Message".




4. Within the Push Message section select the box next to "Enable" and then select "Apply" to save. (Reference image via the next page)





CLEAR - VMS Phone Application Push Settings

1. Open up the CLEAR VMS phone application via your Iphone or Android device.
2. Select the menu  option located within the top left corner of the application and then select the option labeled "Push Settings".



3. Within the Push Setting select the device you would like to enable Push notifications for. In this setup we will be selecting the option labeled testdemo.







4. This will prompt you to a new page in which you will enable the option labeled **“Device Notification Function”**.



5. Doing so will extend out multiple options allowing you to choose what type of push notifications you would like to receive. In this guide we will demonstrate enabling a motion triggered push notification. To do so simply select the option labeled **“Motion”**.




6. Select the camera(s) you would like to receive motion triggered push notifications for and once complete select the save icon located within the top right corner.



Receiving/Reviewing Push Notifications

Once all push notifications required are set and saved, you will then receive a notification whenever the alarms enabled are triggered.



In order to review your notification(s) you can either select the notification when triggered via your mobile phone or you can navigate to the notification section within the CLEAR VMS application. The notification section is found within the applications main menu.



review an alarm simply select the option within the list.

Within the Notification section you will find all of the triggered alarms that have been set off. To

This option allows the user to pull up the live feed for the triggered event.

This option allows the user to pull up the recorded footage for the triggered event.

This option allows the user to trigger an external alarm output that is hooked to the XVR/NVR

This option allows the user to delete the triggered notification.