





## CLEAR™ SERIES EMAIL UPON MOTION SETUP GUIDE

# Email Configuration

## Sender Setup

1. Hook up your CLEAR device to your display monitor and login to your administrator account.

2. Select the "Menu option"  and then select "Settings".  Settings

3. Navigate to the Network settings and select "Email".



4. Fill in all of the fields with the corresponding email information. Reference image on next page. Note: Gmail is our recommended email provider to work with in setting this option up.

Thank you for using [www.freepdfconvert.com](http://www.freepdfconvert.com) service!

Only two pages are converted. Please Sign Up to convert all pages.

<https://www.freepdfconvert.com/membership>