





CLEAR SERIES NAT QUICK SETUP FOR REMOTE VIEWING

# NAT Setup

1. Hook up your CLEAR device to your display monitor and login to your administrator account.
2. Select the "Menu option"  and then select "Settings" .
3. Navigate to the Network settings and select "Network".







4. Select the "NAT" tab located on the top of the page.
5. Select the box next to **Enable** and then select **Apply** to save.



# Remote View Configuration

## CLEAR Phone Application

1. Open the **CLEAR-VMS Phone** application.
2. Select the menu icon located in the top left corner of the application and then select "**Server List**" to add a new device using the NAT feature.
3. Within the Server List section select the plus sign to add a new device. 
4. Select the scan icon. 
5. Scan the QR code located within your CLEAR devices NAT section. 
6. Fill in the **Name** you'd like to call the device, the **Username** and **Password** of your CLEAR device and then select "**Preview**" to review your cameras and save.




# CLEAR Web Application

1. On a PC open up Internet Explorer.
2. Go to "www.autonat.com".
3. Type in your CLEAR devices "Serial number", "Username" and "Password".
4. Select **Login**.




## CLEAR VMS

Navigate to and then open the CLEAR VMS application.



3. Select "Add Device".



4. Select "Manually Add".
5. Change the IP/Domain/Serial number option to Serial Number.
6. Fill in all fields with the corresponding information to your device. These options include: **Device Name, Serial Number, Username, and Password.**
7. Once all fields are filled in with the correct information select "Add".

